


FIG. 2






FIG. 3




FIG. 4




FIG. 5




FIG. 6

FIG. 5 and FIG. 6 are schematic diagrams of the control unit and burner assembly, respectively, showing the various components and their interconnections.




FIG. 10A is a perspective view of the device 60 in an open position. The device 60 includes a housing 64 and a lid 65. The housing 64 includes a front panel 66 and a back panel 67. The lid 65 includes a top panel 68 and a bottom panel 69. The device 60 is shown in an open position with the lid 65 hinged to the housing 64. The device 60 includes a control panel 70 on the front panel 66. The control panel 70 includes a display 71 and a set of buttons 72. The device 60 is shown in a perspective view from the front and slightly to the right.

64

65

66




FIG. 10A

65

66



FIG. 10B

45

67

64

83

83

FIG. 10C

68

